

FIREBIRD

BRAKE CONTROL

ALPHABETICAL INDEX GROUP 4.500

A	C (Cont'd.)
ADAPTER PACKAGE	COVER (Cont'd.)
POWER BRAKE 4.898	MASTER CYLINDER RESERVOIR 4.651
B	COVER OR PAD
BEARING	BRAKE PEDAL 4.630
POWER BRAKE VACUUM CYLINDER POWER PISTON 4.924	PARKING BRAKE PEDAL 4.630
BOLT	CUP
BRAKE PEDAL PIVOT 4.634	MASTER CYLINDER PISTON 4.654
DISC BRAKE INBOARD TO OUTBOARD HOUSING 4.665	WHEEL BRAKE CYLINDER PISTON 4.667
FRONT BRAKE CALIPER 4.665	CYLINDER ASSEMBLY
FRONT BRAKE HOSE 4.681	BRAKE MASTER 4.650
MASTER CYLINDER STOP 4.653	VACUUM POWER BRAKE 4.901
BOOT	WHEEL BRAKE 4.665
FRONT DISC BRAKE PISTON 4.670	
MASTER CYLINDER PUSH ROD 4.659	D
POWER BRAKE VACUUM CYLINDER 4.659	DIAPHRAGM
WHEEL CYLINDER 4.670	MASTER CYLINDER RESERVOIR 4.651
BRACKET	POWER BRAKE VACUUM CYLINDER POWER PISTON 4.922
BRAKE COMBINATION VALVE MOUNTING 4.690	DISTRIBUTOR AND SWITCH
BRAKE PIPE DISTRIBUTOR AND SWITCH 4.874	BRAKE PIPE 4.874
FRONT BRAKE HOSE 4.681	
FRONT BRAKE PRESSURE REGULATOR VALVE 4.690	E
PARKING BRAKE REAR CABLE 4.785	EQUALIZER
POWER BRAKE VACUUM PIPE 4.930	PARKING BRAKE REAR CABLE 4.765
REAR BRAKE HOSE 4.681	EXTENSION
BRACKET ASSEMBLY	BRAKE PEDAL RETURN SPRING 4.639
BRAKE PEDAL 4.634	
BUMPER	F
BRAKE PEDAL 4.634	FILTER
POWER BRAKE VACUUM CYLINDER REACTION 4.918	POWER BRAKE VACUUM CYLINDER AIR 4.913
BUSHING	FITTING
BRAKE PEDAL SHAFT 4.626	POWER BRAKE VACUUM PIPE TO CARBURETOR 4.930
FRONT BRAKE CALIPER SUPPORT BOLT 4.665	TRANSMISSION TO CARBURETOR VACUUM PIPE 4.930
C	
CABLE ASSEMBLY	G
PARKING BRAKE 4.779	GASKET
CALIPER ASSEMBLY	MASTER CYLINDER MOUNTING 4.648
FRONT WHEEL DISC BRAKE 4.665	GROMMET
CLAMP	FRONT BRAKE PIPE 4.685
POWER BRAKE VACUUM HOSE AND PIPE TO BRACKET 4.930	POWER BRAKE VACUUM CHECK VALVE 4.955
CLEVIS	GUIDE
MASTER CYLINDER PUSH ROD 4.662	PARKING BRAKE CABLE 4.785
CLIP	
BRAKE PIPE 4.686	H
PARKING BRAKE FRONT CABLE CLEVIS 4.785	HANDLE
CLIP ASSEMBLY	PARKING BRAKE RELEASE 4.592
REAR BRAKE PIPE 4.686	HOSE
CONNECTOR	BRAKE 4.680
PARKING BRAKE REAR CABLE 4.765	VACUUM POWER BRAKE FITTING TO VACUUM CYLINDER 4.931
COVER	HOUSING
FRONT BRAKE BLEEDER SCREW 4.666	DISC BRAKE 4.665
MASTER CYLINDER PUSH ROD HOLE TO DASH 4.658	

FIREBIRD ALPHABETICAL INDEX

H (Cont'd.)

HOUSING ASSEMBLY
POWER BRAKE VACUUM CYLINDER 4.906

I

INSERT
BRAKE TUBE SEAT /INBOARD HOUSING/ 4.671
BRAKE TUBE SEAT /REAR/ 4.671
MASTER CYLINDER OUTLET TUBE 4.671
MASTER CYLINDER PIPE CONNECTOR BOLT 4.661

L

LEVER
POWER BRAKE VACUUM CYLINDER REACTION 4.934

N

NUT
BRAKE PEDAL PIVOT 4.634
BRAKE PIPE CONNECTORS 4.685
MASTER CYLINDER TO REAR BRAKE PIPE 4.685
PARKING BRAKE LEVER 4.591
POWER BRAKE VACUUM CYLINDER TO CARBURETOR 4.930

P

PAD
CLUTCH PEDAL COVER 4.630

PEDAL AND LEVER ASSEMBLY
PARKING BRAKE RELEASE 4.591

PEDAL AND PAD COVER
PARKING BRAKE RELEASE 4.591

PEDAL ASSEMBLY
BRAKE 4.625

PIN
MASTER CYLINDER CLEVIS TO PEDAL 4.634

PIPE
FRONT BRAKE 4.685
MASTER CYLINDER 4.685
PRESSURE REGULATING VALVE 4.685
REAR BRAKE 4.685

PIPE ASSEMBLY
FRONT BRAKE EXTENSION 4.685
INTAKE MANIFOLD TO VACUUM CYLINDER 4.930

PISTON
FRONT DISC BRAKE SHOE ACTUATOR 4.668
MASTER CYLINDER 4.653
POWER BRAKE VACUUM CYLINDER 4.922
WHEEL CYLINDER 4.668

PISTON ASSEMBLY
FRONT DISC BRAKE CALIPER 4.668

PLATE
BRAKE PEDAL PAD 4.630
BRAKE PEDAL PAD COVER TRIM 4.630
CLUTCH PEDAL TRIM PAD 4.630
PARKING BRAKE PEDAL PAD COVER TRIM 4.630
POWER BRAKE VACUUM CYLINDER REACTION 4.934

POWER BRAKE UNIT /ACCESSORY/ 4.898

PROTECTOR
MASTER CYLINDER PISTON CUP 4.659

R

REPAIR KIT
BRAKE MASTER CYLINDER 4.649
FRONT BRAKE CALIPER PISTON 4.667
POWER BRAKE VACUUM CYLINDER 4.898

R (Cont'd.)

REPAIR KIT (Cont'd.)
WHEEL CYLINDER OR DISC BRAKE HOUSING PISTON 4.665

RETAINER
MASTER CYLINDER CLEVIS TO PEDAL 4.662
MASTER CYLINDER COVER 4.651
MASTER CYLINDER PISTON SPRING 4.655
MASTER CYLINDER PUSH ROD 4.659
PARKING BRAKE CABLE RETURN SPRING 4.785
PARKING BRAKE RELEASE CABLE 4.785
PEDAL SHAFT TO PEDAL MOUNTING BRACKET 4.634
POWER BRAKE VACUUM CYLINDER AIR VALVE SPRING 4.918
POWER BRAKE VACUUM CYLINDER FLOATING CONTROL VALVE 4.935
POWER BRAKE VACUUM CYLINDER REACTION LEVER 4.934

RING
MASTER CYLINDER PRIMARY PISTON RETAINER 4.656
POWER BRAKE AIR VALVE SPRING RETAINER 4.918
POWER BRAKE VACUUM CYLINDER CHECK VALVE LOCK 4.935
POWER BRAKE VACUUM CYLINDER SILENCER 4.913

ROD
MASTER CYLINDER PUSH 4.658
PARKING BRAKE RELEASE 4.594
POWER BRAKE VACUUM CYLINDER POWER PISTON ADJUSTER 4.924
WHEEL CYLINDER CONNECTING 4.675

S

SCREW
MASTER CYLINDER PRIMARY PISTON EXTENSION 4.654
MASTER CYLINDER SECONDARY PISTON STOP 4.656

SCREW AND LOCKWASHER
PARKING BRAKE PEDAL AND LEVER TO INSTRUMENT PANEL 4.591
REAR WHEEL CYLINDER 4.665

SCREW AND WASHER
REAR BRAKE HOSE BRACKET TO UNDERBODY 4.681

SEAL
FRONT DISC BRAKE SHOE ACTUATOR BLEEDER VALVE /O/ RING 4.666
FRONT DISC BRAKE SHOE ACTUATOR PISTON 4.667
MASTER CYLINDER PISTON 4.654
POWER BRAKE VACUUM CYLINDER AIR VALVE /O/ RING 4.918
POWER BRAKE VACUUM CYLINDER FRONT HOUSING 4.910
POWER BRAKE VACUUM CYLINDER PISTON ROD /O/ RING 4.924

SEAT
WHEEL CYLINDER BRAKE PIPE 4.671

SHAFT
BRAKE PEDAL 4.634

SHIELD
BRAKE AND GAS PIPE 4.685
EMISSION, FUEL AND VAPOR PIPES 4.686

SILENCER
POWER BRAKE VACUUM CYLINDER 4.913

SLEEVE
FRONT BRAKE CALIPER BOLT 4.665
FRONT PARKING BRAKE CABLE 4.785

SPACER
BRAKE PEDAL 4.626
PRESSURE REGULATOR VALVE BRACKET 4.690

SPRING
BRAKE HOSE YOKE 4.681
BRAKE PEDAL ARM RETURN 4.639
FRONT DISC BRAKE CALIPER PISTON RETURN 4.669
MASTER CYLINDER CHECK VALVE 4.655
MASTER CYLINDER PISTON CUP RETURN 4.655
MASTER CYLINDER SECONDARY PISTON 4.655
PARKING BRAKE CABLE RETURN 4.790
PARKING BRAKE PAWL RELEASE LEVER RETURN 4.606

S (Cont'd.)

SPRING (Cont'd.)
 POWER BRAKE VACUUM CYLINDER AIR VALVE 4.918
 POWER BRAKE VACUUM CYLINDER POWER PISTON 4.924
 POWER BRAKE VACUUM CYLINDER REACTION PLATE 4.934
 WHEEL CYLINDER PISTON 4.669

STOP
 MASTER CYLINDER SECONDARY PISTON 4.654

STRAP
 PARKING BRAKE ALARM 4.589

STUD
 PARKING BRAKE PEDAL AND RELEASE LEVER 4.606

SUPPORT
 PARKING BRAKE CABLE 4.785
 POWER BRAKE VACUUM CYLINDER POWER PISTON
 DIAPHRAGM 4.922

SWITCH AND BRACKET ASSEMBLY
 PARKING BRAKE ALARM 4.589

U

UNION
 REAR BRAKE FRONT EXTENSION PIPE 4.898

V

VALVE
 BRAKE COMBINATION 4.690
 FRONT BRAKE PRESSURE REGULATOR 4.690
 MASTER CYLINDER BLEEDER 4.657
 MASTER CYLINDER CHECK 4.657
 POWER BRAKE VACUUM CHECK 4.955
 REAR BRAKE PRESSURE REGULATOR 4.690
 WHEEL BRAKE CYLINDER BLEEDER 4.666

VALVE AND PUSH ROD ASSEMBLY
 POWER BRAKE VACUUM CYLINDER AIR 4.918

VALVE KIT
 POWER BRAKE VACUUM CYLINDER FLOATING CONTROL ... 4.935

W

WASHER
 BRAKE PEDAL ARM TO POWER CYLINDER PUSH ROD 4.634
 MASTER CYLINDER CLEVIS TO PEDAL 4.659
 PIPE CONNECTOR AND BRAKE HOSE 4.671
 POWER CYLINDER PUSH ROD LIMITER 4.659

Y

YOKE
 BRAKE HOSE 4.681

.500

BRAKE CONTROL

4.589 STRAP, PARKING BRAKE ALARM

1	3916762	67	ALL
		68	ALL - FIRST TYPE 1 IN WIDE
1	3916762	69	ALL

4.589 SWITCH AND BRACKET ASSEMBLY, PARKING BRAKE ALARM

1	3863390	67-68	ALL
1	3934201	69	ALL
1	3983909	70-76	ALL

4.591 NUT, PARKING BRAKE LEVER

2	271184	67-70	ALL - 5/16-18 /SUP 274218/
---	--------	-------	----------------------------

4.591 PEDAL AND LEVER ASSEMBLY, PARKING BRAKE RELEASE

1	9796195	67-69	ALL /SUP 3928357/
1	481955	70-76	ALL /SUP 480368/

4.591 PEDAL AND PAD COVER, PARKING BRAKE RELEASE

1	500039	75-76	ALL
---	--------	-------	-----

4.591 SCREW AND LOCKWASHER, PARKING BRAKE PEDAL AND LEVER TO INSTRUMENT PANEL

1	3856691	67-68	ALL
---	---------	-------	-----

4.592 HANDLE, PARKING BRAKE RELEASE

1	3893179	67-69	ALL
1	480376	70-76	ALL - INCLUDES CABLE

4.594 ROD, PARKING BRAKE RELEASE

1	9796801	67-68	ALL - SECOND TYPE 5-1/16 IN LONG
		69	ALL

4.606 SPRING, PARKING BRAKE PAWL RELEASE LEVER RETURN

1	3953286	67-68	ALL /SUP 3893174/
---	---------	-------	-------------------

4.606 STUD, PARKING BRAKE PEDAL AND RELEASE LEVER

1	3982308	70-76	ALL - TO BODY - 5/16-18 X 3-1/8
---	---------	-------	---------------------------------

4.625 PEDAL ASSEMBLY, BRAKE

1	3890801	67	ALL ST /SUP 3890601/
1	3923545	67	ALL AT OR HT /SUP 3890605/
1	3923541	68	ALL ST
1	3923545	68	ALL AT OR HT
1	9798202	69	ALL ST
1	9798200	69	ALL AT OR HT
1	3965697	70-74	ALL ST
1	3972201	70-74	ALL AT
1	347401	75	ALL ST
1	347403	75	ALL AT
1	368064	76	ALL AT
1	368063	76	ALL ST

4.626 BUSHING, BRAKE PEDAL SHAFT

2	3965692	67-72	ALL
2	342482	73-74	ALL
2	1247439	75-76	ALL

4.626 SPACER, BRAKE PEDAL

1	529323	69-76	ALL - STEEL TUBING 7/16 ID X 2-3/8 LONG - CUT TO SIZE
---	--------	-------	---

4.630 COVER OR PAD, BRAKE PEDAL

1	3921648	67-68	ALL ST
1	3888682	67-68	ALL AT OR HT
1	3921648	69	ALL ST /SUP 9776819/
1	9774235	69	ALL AT OR HT
1	3921648	70-76	ALL ST
1	3888682	70-75	ALL AT

4.630 COVER OR PAD, PARKING BRAKE PEDAL

1	3893181	67-68	ALL
1	9791740	69	ALL
1	3945593	70-76	ALL

4.630 PAD, CLUTCH PEDAL COVER

1	332515	73-76	ALL
---	--------	-------	-----

4.630 PLATE, BRAKE PEDAL PAD

1	3923615	67	ALL ST /SUP 3888679/
1	9777718	68	ALL ST
1	9778267	69	ALL ST
1	3923615	70	ALL ST
		73-76	ALL ST

4.630 PLATE, BRAKE PEDAL PAD COVER TRIM

1	3888683	67	ALL WITH AT OR HT
1	9777717	68	ALL WITH AT OR HT
1	9788316	69	ALL AT OR HT
1	3888683	70	ALL PG OR HT
		74-75	AT

4.630 PLATE, CLUTCH PEDAL TRIM PAD

1	491627	74-76	ALL ST
---	--------	-------	--------

4.630 PLATE, PARKING BRAKE PEDAL PAD COVER TRIM

1	3893182	67-68	ALL
1	9781281	69	ALL

4.634 BOLT, BRAKE PEDAL PIVOT

1	399803	69-72	ALL ST
1	454948	69	ALL AT OR HT - 7/16-14 X 2-1/2

4.634 BRACKET ASSEMBLY, BRAKE PEDAL

1	3918739	68	ALL
1	9796057	69	ALL
1	3996355	70-76	ALL - NOTE - FOR 1970 MAY BE NECESSARY TO SHORTEN TWO LOWER MOUNTING STUDS BY CUTTING

4.634 BUMPER, BRAKE PEDAL

1 340688 67 ALL /SUP 3889905/

4.634 NUT, BRAKE PEDAL PIVOT

1 9422299 69-72 ALL - 7/16-14

4.634 PIN, MASTER CYLINDER CLEVIS TO PEDAL

1 3817879 67-69 ALL
1 3965696 70 ALL SB
1 3975544 70-76 ALL PB
1 3992577 71-75 ALL EXC PB

4.634 RETAINER, PEDAL SHAFT TO PEDAL MOUNTING BRACKET

1 3828428 67-68 ALL AT OR HT

4.634 SHAFT, BRAKE PEDAL

1 3828427 67-68 ALL AT OR HT

4.634 WASHER, BRAKE PEDAL ARM TO POWER CYLINDER PUSH ROD

AR 385071 69 ALL WITH ST - SPRING TYPE
1 410230 71-76 ALL - 11/16 OD X 29/64 ID - WAVE TYPE

4.639 EXTENSION, BRAKE PEDAL RETURN SPRING

1 3841645 67 ALL SB
1 3991374 71-76 ALL SB

4.639 SPRING, BRAKE PEDAL ARM RETURN

1 3850084 67 ALL SB
1 9785936 68 ALL SB - COIL
69 ALL SB - WITH CRUISE CONTROL - COIL
1 3850084 70-75 ALL SB

4.648 GASKET, MASTER CYLINDER MOUNTING

1 3792566 67 ALL SB
70-76 ALL SB

4.649 REPAIR KIT, BRAKE MASTER CYLINDER

1 5468449 67 ALL WITH DB
1 5468453 67 ALL EXC DB /SUP -5463227-/
1 5468331 68-69 ALL EXC DB
1 5468337 68 ALL WITH DB
1 5469286 69 ALL WITH DB
1 5471960 70 ALL EXC PB /SUP 5471147/
1 18001017 70-74 ALL PB /SUP 5470766/
1 5468867 71-74 ALL EXC PB
1 335152 75 PB /BENDIX/
1 18001017 75 PB /MORAINES/ - USED ON CYL W/SINGLE BAIL /SUP 5470766/
1 2623066 75 ALL EXC PB - MORAINES
1 18001017 76 POWER DISC BRAKES - FRONT - MORAINES
1 18001021 76 ALL W/MANUAL FRONT DISC BRAKES - MORAINES

4.650 CYLINDER ASSEMBLY, BRAKE MASTER

1 5472651 67 ALL EXC DB - 1 DIA /SUP 5458523/
1 5463492 67 ALL WITH DB - 1-1/8
1 5471817 68-69 ALL EXC DB /SUP 5458522/
1 5459784 68 ALL WITH DB
1 5469357 69 ALL WITH DB
1 5472652 70-74 ALL EXC PB - LESS PUSH ROD /SUP 5471958/
1 2622655 70-74 ALL PB /SUP 5470664/
1 346405 75 ALL PB - BENDIX
1 5471802 75 ALL PB - MORAINES
1 2623065 75 EXC PB - MORAINES

4.650 CYLINDER ASSEMBLY, BRAKE MASTER

(Cont'd)

1 18000996 76 ALL PB - MORAINES - 1.187 IN DIA
1 18001112 76 ALL W/MANUAL FRONT DISC BRAKES - MORAINES

4.651 COVER, MASTER CYLINDER RESERVOIR

1 5452320 67-69 ALL EXC DB
1 5455517 67-69 ALL WITH DB
1 5455517 70-74 ALL SB
1 5470405 70-75 ALL PB - MORAINES
1 6259024 75 ALL PB - BENDIX
1 18000779 76 ALL - MORAINES

4.651 DIAPHRAGM, MASTER CYLINDER RESERVOIR

1 5455516 67-69 ALL WITH DB
1 5470861 67-69 ALL EXC DB /SUP 5452319/
1 5455516 70-74 ALL SB
1 18002172 70-76 ALL PB - MORAINES /SUP 5470404/
1 409353 75 ALL PB - BENDIX

4.651 RETAINER, MASTER CYLINDER COVER

2 5455518 67-68 ALL WITH DB
1 5452321 67 ALL EXC DB
1 5468053 68-69 ALL EXC DB
1 5468305 69 ALL WITH DB - WIRE
2 5468103 70-74 ALL SB
1 5470407 70-76 ALL PB - MORAINES
1 409354 75 ALL PB - BENDIX

4.653 BOLT, MASTER CYLINDER STOP

1 335153 75 ALL PB - BENDIX

4.653 PISTON, MASTER CYLINDER

1 5460877 67 ALL EXC DB - PRIMARY
1 5452694 67-69 ALL EXC DB - SECONDARY
1 5468451 67 ALL WITH DB - PRIMARY /SUP 5455860/
1 5460257 67-69 ALL WITH DB - SECONDARY
1 5452318 68 ALL EXC DB - PRIMARY
1 5470811 70-74 ALL SB - SECONDARY
1 5468776 70-74 ALL PB - SECONDARY
1 335161 75 ALL PB - PRIMARY - BENDIX
1 6263170 75 ALL PB - SECONDARY - BENDIX
1 5471610 75-76 ALL PB - SECONDARY - MORAINES
1 18001192 76 ALL MANUAL DISC BRAKES - SECONDARY - MORAINES

4.654 CUP, MASTER CYLINDER PISTON

2 5453620 67-74 ALL EXC DB - PRIMARY
2 5460195 69-74 ALL EXC DB - SECONDARY
1 409349 74-75 ALL - PRIMARY PISTON - DOUBLE LIP - BENDIX
1 5455859 75 ALL PB - PRIMARY - MORAINES
1 5455858 75 ALL PB - SECONDARY - MORAINES

4.654 SCREW, MASTER CYLINDER PRIMARY PISTON EXTENSION

1 5452519 67 ALL

4.654 SEAL, MASTER CYLINDER PISTON

1 5460195 67-69 ALL EXC DB - PRIMARY
2 5455859 67-72 ALL WITH DB - PRIMARY
1 5460195 70-72 ALL SB - PRIMARY
2 5455859 70-74 ALL PB - PRIMARY
2 5460195 67-69 ALL EXC DB - SECONDARY
3 5455858 67-72 ALL WITH DB - SECONDARY
1 5460195 70-72 ALL SB - SECONDARY
3 5455858 70-74 ALL PB - SECONDARY

FIREBIRD

4.654
BRAKE
CONTROL

4.654 SEAL, MASTER CYLINDER PISTON (Cont'd)

1 6263171 75 ALL PB - SECONDARY -
BENDIX

4.654 STOP, MASTER CYLINDER SECONDARY PISTON

1 5452315 67 ALL

4.655 RETAINER, MASTER CYLINDER PISTON SPRING

1 5460627 67-72 ALL WITH DB - SECONDARY
1 5451070 67-69 ALL EXC DB - SECONDARY
1 5451070 70-74 ALL SB
1 5460627 70-75 ALL PB - SECONDARY -
MORAINE

4.655 SPRING, MASTER CYLINDER CHECK VALVE

1 5462637 67-68 ALL
69 ALL EXC DB

4.655 SPRING, MASTER CYLINDER SECONDARY PISTON

1 5455515 67-69 ALL WITH DB
70-75 ALL PB - MORAINE
1 5460806 70-74 ALL SB
1 231375 75 ALL PB - BENDIX

4.655 SPRING, MASTER CYLINDER PISTON CUP RETURN

1 5452313 67-69 ALL EXC DB - SECONDARY /
SUP 5452314/
1 5452520 67 ALL - PRIMARY

4.656 RING, MASTER CYLINDER PRIMARY PISTON RETAINER

1 5467356 67-69 ALL EXC DB
70-74 ALL SB
1 231495 75 ALL PB - BENDIX

4.656 SCREW, MASTER CYLINDER SECONDARY PISTON STOP

1 5464418 67-75 ALL - MORAINE

4.657 VALVE, MASTER CYLINDER BLEEDER

1 5469230 67-72 ALL /SUP 5462945/

4.657 VALVE, MASTER CYLINDER CHECK

1 5462642 67-68 ALL
69 ALL EXC DB

4.658 COVER, MASTER CYLINDER PUSH ROD HOLE TO DASH

1 9788697 70-76 STD BRAKES

4.658 ROD, MASTER CYLINDER PUSH

1 3790222 67 ALL EXC PB
1 5468654 68 ALL EXC PB
1 5472426 70 ALL SB /SUP 5471949/
1 5472426 71-74 ALL EXC PB
1 2622210 75 EXC PB
1 2622996 76 ALL EXC PB - MORAINE

4.659 BOOT, MASTER CYLINDER PUSH ROD

1 5456779 67 ALL EXC PB
1 5452526 68-74 ALL EXC PB

4.659 BOOT, POWER BRAKE VACUUM CYLINDER

1 5452997 67-69 ALL

4.659 PROTECTOR, MASTER CYLINDER PISTON CUP

2 5462635 67-75 ALL - FOR PRIMARY CUP -
MORAINE

4.659 RETAINER, MASTER CYLINDER PUSH ROD

1 5452525 68-74 ALL EXC PB

4.659 WASHER, MASTER CYLINDER CLEVIS TO PEDAL

1 3953987 67 ALL WITH PB
68 ALL /SUP 3788262/

4.659 WASHER, POWER CYLINDER PUSH ROD LIMITER

1 5464812 67-68 ALL WITH PB OR DB
69-72 ALL WITH PB

4.661 INSERT, MASTER CYLINDER PIPE CONNECTOR BOLT

AR 5452322 73-74 ALL /MORAINE/

4.662 CLEVIS, MASTER CYLINDER PUSH ROD

1 3953288 67-69 ALL /SUP 5468524/
1 9787638 68 ALL - EXC PB - END

4.662 RETAINER, MASTER CYLINDER CLEVIS TO PEDAL

1 3817880 67-75 ALL

4.665 BOLT, DISC BRAKE INBOARD TO OUTBOARD HOUSING

4 9422268 67-68 ALL WITH DB /SUP 5463355/

4.665 BOLT, FRONT BRAKE CALIPER

4 5463495 69-76 ALL

4.665 BUSHING, FRONT BRAKE CALIPER SUPPORT BOLT

4 5470497 69-76 ALL WITH DB - OUTER - 3/8 IN
ID /SUP 5463313/
4 5469178 69-76 ALL WITH DB - INNER - 5/8 IN
ID

4.665 CALIPER ASSEMBLY, FRONT WHEEL DISC BRAKE

1 5463807 69 ALL - RIGHT - WITH HOUSING
AND PISTON
1 5463806 69 ALL - LEFT - WITH HOUSING
AND PISTON
1 2620586 70-71 ALL - RIGHT /SUP 5474056/
1 2620585 70-76 ALL - LESS SHOE AND LININGS
- LEFT /SUP 5472532/
1 2620586 72 ALL - LESS SHOE AND LINING
- RIGHT /SUP 5474056/
1 2620586 73-76 ALL - LESS SHOE AND LINING
- RIGHT

4.665 CYLINDER ASSEMBLY, WHEEL BRAKE

1 5469304 67-68 ALL EXC DB - FRONT - RIGHT
1 5469303 67-68 ALL EXC DB - FRONT - LEFT
2 5469245 67-68 ALL - REAR - 7/8
1 5469304 69 ALL EXC DB - FRONT - RIGHT
1 5469303 69 ALL EXC DB - FRONT - LEFT
2 5469245 69-75 ALL - REAR
2 5469321 76 ALL - REAR - 15/16 IN DIA

4.665 HOUSING, DISC BRAKE

1 5468364 67 ALL WITH DB - INBOARD - 1ST
TYPE WITH 3/8 BRAKE PIPE
HOLE - RIGHT /SUP 5462043/

4.665 HOUSING, DISC BRAKE (Cont'd)

1	5468364	67	ALL WITH DB - INBOARD - 2ND TYPE ON RIGHT HAND WITH 7/16 BRAKE PIPE HOLE - RIGHT
1	5468363	67	ALL WITH DB - INBOARD - 2ND TYPE ON LEFT HAND WITH 1/2 BRAKE PIPE HOLE - LEFT
2	5456076	67-68	ALL WITH DB - OUTBOARD
1	5468364	68	ALL WITH DB - INBOARD - RIGHT
1	5468363	68	ALL WITH DB - INBOARD - LEFT

4.665 REPAIR KIT, WHEEL CYLINDER OR DISC BRAKE HOUSING PISTON

2	5465083	67-69	ALL EXC DB - FRONT
2	5466562	67-73	ALL - REAR /SUP 5464848/
8	5463232	67-68	ALL WITH DB - FRONT - CONTAINS 1 OF SEAL, BOOT AND O-RING
2	5468767	69-73	ALL WITH DB - FRONT - INCL PISTON, SEAL AND BOOT
AR	5466562	74-75	ALL - REAR

4.665 SCREW AND LOCKWASHER, REAR WHEEL CYLINDER

4	5463185	73-76	ALL
---	---------	-------	-----

4.665 SLEEVE, FRONT BRAKE CALIPER BOLT

4	5468225	69-74	ALL WITH DB /SUP 5474406/
4	5474406	75-76	ALL

4.666 COVER, FRONT BRAKE BLEEDER SCREW

2	5469581	74-75	ALL W/DISC BRAKES - PLASTIC
---	---------	-------	-----------------------------

4.666 SEAL, FRONT DISC BRAKE SHOE ACTUATOR BLEEDER VALVE /O/ RING

4	5465969	67-68	ALL WITH DB
---	---------	-------	-------------

4.666 VALVE, WHEEL BRAKE CYLINDER BLEEDER

4	5469230	67-68	ALL /SUP 5462945/
4	5469230	69-76	ALL EXC DB
2	5455122	69-76	ALL WITH DB - FRONT - 3/8-24 X 1-1/8 - MORaine

4.667 CUP, WHEEL BRAKE CYLINDER PISTON

4	N.L.A.	67-69	ALL EXC DB - FRONT - 1-1/8 DIA /SUP 5455298/
4	N.L.A.	67-72	ALL - REAR - /ILL. 5-1/ /SUP 5455481/

4.667 REPAIR KIT, FRONT BRAKE CALIPER PISTON

2	5468767	69-76	ALL WITH DB - INCL 2 SEALS / SUP 5463484/
---	---------	-------	---

4.667 SEAL, FRONT DISC BRAKE SHOE ACTUATOR PISTON

8	5467984	67-68	ALL WITH DB
---	---------	-------	-------------

4.668 PISTON ASSEMBLY, FRONT DISC BRAKE CALIPER

2	2622207	69-76	ALL
---	---------	-------	-----

4.668 PISTON, FRONT DISC BRAKE SHOE ACTUATOR

8	5457273	67-68	ALL WITH DB
---	---------	-------	-------------

4.668 PISTON, WHEEL CYLINDER

4	5465083	67-69	ALL EXC DB - FRONT /SUP 5461017/
4	5461429	67-72	ALL - REAR - /ILL. 5-1/

4.669 SPRING, FRONT DISC BRAKE CALIPER PISTON RETURN

8	5466733	67-68	ALL WITH DB
2	5469180	69	ALL - FIRST TYPE - HAIR PIN TYPE - USED ON SHOES WITH CIRCULAR NOTCH OR UNNOTCHED
2	5469497	69	ALL - SECOND TYPE - CLIP-ON TYPE - USED ON SHOES WITH SMALL FLAT NOTCH
		70-76	ALL

4.669 SPRING, WHEEL CYLINDER PISTON

2	5455487	67-69	ALL EXC DB - FRONT - WITH EXPANDER - 1-1/8 DIA
2	5455421	67-72	ALL - REAR - WITH EXPANDER - /ILL. 5-1/

4.670 BOOT, FRONT DISC BRAKE PISTON

8	5467987	67-68	ALL WITH DB
2	5468767	69-70	ALL - BRAKE HOUSING PISTON /SUP 5463296/

NOTE. FOR USAGE AFTER 1970 SEE BRAKE HOUSING PISTON REPAIR KIT GR. 4.665.

4.670 BOOT, WHEEL CYLINDER

4	5464988	67-69	ALL EXC DB - FRONT
---	---------	-------	--------------------

4.671 INSERT, BRAKE TUBE SEAT /INBOARD HOUSING/

AR	5453786	67-68	ALL WITH DB - USE WITH HOUSINGS THAT HAVE A 3/8 OR 7/16 HOLE
1	5452322	67-68	ALL WITH DB - USE WITH HOUSINGS THAT HAVE A 1/2 HOLE

4.671 INSERT, BRAKE TUBE SEAT /REAR/

2	5453786	67-75	ALL
---	---------	-------	-----

4.671 INSERT, MASTER CYLINDER OUTLET TUBE

1	5452322	67-75	ALL
---	---------	-------	-----

4.671 SEAT, WHEEL CYLINDER BRAKE PIPE

2	6273937	75	ALL
---	---------	----	-----

4.671 WASHER, PIPE CONNECTOR AND BRAKE HOSE

2	231343	67-70	ALL - 7/16 ID X 11/16 OD - COPPER
---	--------	-------	-----------------------------------

4.675 ROD, WHEEL CYLINDER CONNECTING

8	5464748	67-69	ALL EXC DB
4	5464748	70-76	ALL - REAR - TO BRAKE SHOE THRUST

4.680 HOSE, BRAKE

2	3910718	67	ALL EXC DB - FRONT
2	9791649	67-68	ALL WITH DB - FRONT
1	9749977	67-68	ALL - REAR /SUP 9745246/
2	9745221	68-69	ALL EXC DB - FRONT
2	9753906	69	ALL WITH DB - FRONT /SUP 3953294/
1	9755607	69	ALL - REAR /SUP 9753904/
2	3984577	70	ALL - FRONT /SUP 3975501/
1	9755607	70-72	ALL - REAR - SEE NOTE /SUP 9753904/
2	9753907	71	ALL - FRONT /SUP 3984577/
2	9753907	72-73	ALL - FRONT
1	9755607	73	ALL - REAR
2	9758860	74-75	ALL - FRONT /SUP 352892/
1	9757657	74-75	ALL - REAR
1	9758860	76	ALL - FRONT

4.680 HOSE, BRAKE (Cont'd)

1 9758883 76 ALL - REAR

NOTE. FOR 1970-71 USAGE IT MAY BE NECESSARY TO REWORK FRAME BRACKET.

4.681 BOLT, FRONT BRAKE HOSE

2 487293 69-76 ALL - 7/16-20 X 15/16

4.681 BRACKET, FRONT BRAKE HOSE

1 9785915 67-68 ALL WITH DB - FRAME - RIGHT
 1 9789431 67-68 ALL WITH DB - TO BRAKE SUPPORT - RIGHT
 1 3955702 69 ALL WITH DB - FRAME - RIGHT
 1 6264027 69 ALL WITH DB - FRAME - LEFT / SUP 3958439/
 1 6264042 70-73 ALL - FRAME - RIGHT /SUP 3975500/
 1 6264041 70-73 ALL - FRAME - LEFT /SUP 3975499/
 1 340322 74-76 ALL - TO FRAME - RIGHT
 1 340321 74-76 ALL - TO FRAME - LEFT

4.681 BRACKET, REAR BRAKE HOSE

1 3893145 67-68 ALL - TO UNDERBODY
 1 9797466 69 ALL - TO DIFFERENTIAL CASE COVER
 1 6264043 70-73 ALL /SUP 3975502/
 1 340317 74-75 ALL
 1 368119 76 ALL

4.681 SCREW AND WASHER, REAR BRAKE HOSE BRACKET TO UNDERBODY

2 839896 67-68 ALL

4.681 SPRING, BRAKE HOSE YOKE

AR 334961 73-76 ALL

4.681 YOKE, BRAKE HOSE

AR 334961 67-72 ALL - TO CROSSMEMBER BRACKET
 67-72 ALL - FRONT HOSE TO SUPPORT BRACKET
 67-72 ALL - REAR HOSE TO AXLE HOUSING AND BRACKET /SUP 476737/

4.685 GROMMET, FRONT BRAKE PIPE

1 3983038 70-76 ALL

4.685 NUT, MASTER CYLINDER TO REAR BRAKE PIPE

1 9424955 67 ALL

4.685 NUT, BRAKE PIPE CONNECTORS

AR 137396 ALL MODELS/ALL YEARS - INVERTED FLARED TUBE - 3/8-24 THREAD
 AR 137397 67-70 ALL - INVERTED FLARED TUBE - 1/4
 AR 9424955 67-70 ALL - INVERTED FLARED TUBE - 9/16-18 THREAD

4.685 PIPE, MASTER CYLINDER

1 3904271 67-69 ALL EXC DB - TO DISTRIBUTOR - FRONT
 1 9785959 67-69 ALL - TO DISTRIBUTOR AND SWITCH - REAR
 1 N.L.A. 69 ALL WITH DB - TO PRESSURE METER OR REGULATOR VALVE - USE STEEL TUBING FROM BULK ROLL - S.S. GRP. 8.964
 1 3980974 70 ALL - TO DISTRIBUTOR AND SWITCH - REAR

4.685 PIPE, MASTER CYLINDER (Cont'd)

1 3992570 70 ALL PB - TO METERING VALVE - FRONT /SUP 3980970/

4.685 PIPE ASSEMBLY, FRONT BRAKE EXTENSION

1 3908334 67-69 ALL WITH PB - RIGHT

4.685 PIPE, FRONT BRAKE

1 3909993 67-68 ALL WITH SB - LEFT
 1 9785928 67-68 ALL WITH DB - EXC PB - LEFT
 1 9798649 69 ALL WITH SB - RIGHT
 1 9798650 69 ALL WITH SB - LEFT
 1 9798651 69 ALL WITH PB - EXC DB - RIGHT
 1 9798652 69 ALL WITH PB - EXC DB - LEFT
 1 9798772 69 ALL WITH DB - LEFT

4.685 PIPE, REAR BRAKE

1 3909966 67 ALL WITH PB - WITH DB - EXC AIR COND - FRONT
 1 3909966 67 ALL WITH PB - EXC DB - FRONT
 1 3932777 68 ALL WITH PB - WITH DB - EXC AIR COND - FRONT
 68 ALL WITH PB - EXC DB - FRONT
 1 3932779 68 ALL 8 CYL - EXC PB - WITH DB - WITH AIR COND - FRONT
 1 N.L.A. 68 ALL EXC PB - EXC AIR COND - FRONT /SUP 3932775/
 1 9794105 68 ALL - REAR - LEFT /SUP - 9792694-/
 1 N.L.A. 69 ALL - EXC PB - FRONT /SUP 546471/
 1 N.L.A. 69 ALL 8 CYL WITH DB - WITH AIR COND - FRONT /SUP 3958435/
 1 546472 69 ALL 6 CYL - WITH PB OR DB - FRONT
 69 ALL 8 CYL WITH DB - EXC AIR COND - FRONT
 69 ALL 8 CYL WITH PB - EXC DB - FRONT /SUP 3958434/
 1 N.L.A. 69 ALL - REAR - RIGHT /SUP 9797465/
 1 N.L.A. 69 ALL - REAR - LEFT /SUP 9794674/

4.685 PIPE, PRESSURE REGULATING VALVE

1 3980977 70 ALL - INLET
 1 N.L.A. 70 ALL - OUTLET - USE BULK TUBING
 1 3992543 71-74 SB - FRONT
 1 3992544 71-75 SB - REAR

4.685 SHIELD, BRAKE AND GAS PIPE

AR 3886933 ALL MODELS/ALL YEARS - FOR 1/4 IN OD PIPE - 64-1/2 IN FREE LENGTH - SPRING WOUND COIL TYPE - BLACK ENAMEL - CUT AS REQUIRED

4.686 CLIP ASSEMBLY, REAR BRAKE PIPE

2 3886521 67-68 ALL

4.686 CLIP, BRAKE PIPE

5 3825340 67 ALL /SUP 3881339/
 AR 1380949 68 ALL
 AR 3952717 69-74 ALL - 3/8 CLOSED - BLUE
 AR 343464 69-76 ALL - FRONT PIPE - 5/16 - TYPE 4 - W/TANG - BLUE / SUP 3952718/

FIREBIRD

4.686 CLIP, BRAKE PIPE (Cont'd)

2	3952771	69	ALL 8 CYL - FRONT BRAKE PIPE TO FRAME CROSSMEMBER RH - 3/8-1/4 CLOSED
AR	N.L.A.	69	ALL - REAR BRAKE FRONT PIPE /SUP 3962722/
1	3956700	70-74	ALL - REAR BRAKE PIPE TO AXLE
1	3975504	70-75	ALL - REAR BRAKE HOSE
1	3982380	70-76	ALL - FRONT BRAKE PIPE GROMMET
AR	478601	74-76	ALL - FRONT PIPE - FOR 1/4 AND 3/16 PIPES
AR	478600	73-74	ALL - FOR 3/8 AND 5/16 PIPES - GREEN
1	342653	75	ALL - REAR BRAKE PIPE TO AXLE
AR	343463	75-76	ALL - REAR PIPE - CLOSED TYPE - .375 X .343 - ZINC - NATURAL COLOR
AR	340393	75-76	ALL - FOR 3/8 AND 5/16 PIPES - TYPE 5 - W/TANG - BLUE
AR	340392	75	ALL - FOR 15/32 AND 11/32 PIPES - TYPE 5 - W/TANG - NATURAL COLOR
AR	340391	75-76	ALL - FOR 3/8 AND 1/4 PIPES - TYPE 5 - W/TANG - BLACK
AR	478732	75-76	ALL - TO FRAME - ORANGE
AR	494277	75-76	ALL - TO FRAME - BLUE
AR	340816	75	ALL - PWR BRAKE VACUUM PIPE TO THROTTLE CABLE - FOR .375 PIPE - NO TANG - BLUE

NOTE. ALSO SEE GROUP 3.162 FOR BRAKE, EMISSION, FUEL AND VAPOR RETURN PIPE CLIPS.

4.686 SHIELD, EMISSION, FUEL AND VAPOR PIPES

AR 494775 73-74 ALL

4.690 BRACKET, BRAKE COMBINATION VALVE MOUNTING

1 3992571 71-76 POWER BRAKES

4.690 BRACKET, FRONT BRAKE PRESSURE REGULATOR VALVE

1 3912539 67-69 ALL WITH DB
70 ALL PB
1 3989486 71-76 EXC PB

4.690 SPACER, PRESSURE REGULATOR VALVE BRACKET

1 3989487 71-75 SB

4.690 VALVE, BRAKE COMBINATION

1 5472359 71-72 ALL - INCL SWITCH
73-74 ALL WITH POWER BRAKES - INCL SWITCH
1 2620849 75 STD BRAKES - INCL SWITCH
76 ALL WITH 6 CYL EXC PB - INCL SWITCH
1 2620851 76 ALL WITH POWER BRAKES - INCL SWITCH

4.690 VALVE, FRONT BRAKE PRESSURE REGULATOR

1 3905525 67-69 ALL WITH DB
1 1233464 70 ALL SB

4.690 VALVE, REAR BRAKE PRESSURE REGULATOR

1 N.L.A. 67-69 ALL 8 CYL - WITH DB - WITH AIR COND /SUP 3908326/

4.690 VALVE, REAR BRAKE PRESSURE REGULATOR (Cont'd)

1 3980978 70 ALL

4.765 CONNECTOR, PARKING BRAKE REAR CABLE

2 537485 67-75 ALL

4.765 EQUALIZER, PARKING BRAKE REAR CABLE

1 1497525 67-76 ALL /SUP 6256437/

4.779 CABLE ASSEMBLY, PARKING BRAKE

1 338250 67 ALL - FRONT /SUP 3892741/
1 3914813 67-69 ALL - INTERMEDIATE
2 3988527 67 ALL - REAR /SUP 3914811/
1 338250 68-69 ALL - FRONT /SUP 9793660/
2 9793655 68-69 ALL - REAR
1 3975649 70-74 ALL - FRONT
2 3992584 70-74 ALL - REAR /SUP 3975645/
1 344682 75 ALL - FRONT
2 356548 75-76 ALL - REAR /SUP 344695/

4.785 BRACKET, PARKING BRAKE REAR CABLE

1 3895206 67 ALL - RIGHT
1 3895205 67 ALL - LEFT
1 3983022 70-76 ALL - RIGHT
1 3983021 70-76 ALL - LEFT

4.785 CLIP, PARKING BRAKE FRONT CABLE CLEVIS

1 3992592 67-76 ALL /SUP 3908628/

4.785 GUIDE, PARKING BRAKE CABLE

1 3892744 67-69 ALL - INTERMEDIATE
1 3975648 70-74 ALL - REAR

4.785 RETAINER, PARKING BRAKE CABLE RETURN SPRING

AR 3875092 67-74 ALL
AR 516213 75-76 ALL - AT HANDLE
1 1385078 75-76 ALL - UNDER BODY

4.785 RETAINER, PARKING BRAKE RELEASE CABLE

1 3875092 70 ALL - TO INSTRUMENT PANEL REINFORCEMENT

4.785 SLEEVE, FRONT PARKING BRAKE CABLE

1 3908307 67-69 ALL

4.785 SUPPORT, PARKING BRAKE CABLE

1 9814173 70-74 ALL - RIGHT - ON PAN
1 9814174 70-76 ALL - LEFT - ON PAN
1 1660114 75-76 ALL - RIGHT - ON FLOOR PANEL

4.790 SPRING, PARKING BRAKE CABLE RETURN

1 3996374 70-74 ALL - TO UNDERBODY /SUP 3983025/

4.874 BRACKET, BRAKE PIPE DISTRIBUTOR AND SWITCH

1 3909933 67-69 ALL

4.874 DISTRIBUTOR AND SWITCH, BRAKE PIPE

1 3904270 67-69 ALL
1 3983040 70 ALL - INCL BRACKET
1 5472359 71-72 ALL

- 4.898 ADAPTER PACKAGE, POWER BRAKE**
- 1 N.L.A. 72-73 ALL 8 CYL - USED IN CONJUNCTION WITH POWER BRAKE PACKAGE GROUP 4.898 /SUP 989090/
- 4.898 POWER BRAKE UNIT /ACCESSORY/**
- 1 N.L.A. 68 ALL /SUP 984991/
- 4.898 REPAIR KIT, POWER BRAKE VACUUM CYLINDER**
- 1 5463228 67-69 ALL
- 1 5471249 70-74 ALL
- 1 2623958 75-76 ALL - MORAINE
- 4.898 UNION, REAR BRAKE FRONT EXTENSION PIPE**
- 1 406057 71-73 ALL W/FIELD INSTALLED PB
- 4.901 CYLINDER ASSEMBLY, VACUUM POWER BRAKE**
- 1 5458828 67 ALL WITH DB
- 1 5462049 67 ALL EXC DB
- 1 5463666 68 ALL EXC DB
- 1 N.L.A. 69 ALL EXC DB /SUP 5469210/
- 1 5469345 69 ALL WITH DB - EXC TRANS AM
- 1 N.L.A. 69 ALL WITH DB - WITH TRANS AM /SUP 5469413/
- 1 18000021 70-76 ALL - MORAINE /SUP 5472354/
- 4.906 HOUSING ASSEMBLY, POWER BRAKE VACUUM CYLINDER**
- 1 5467850 67-71 ALL - FRONT
- 1 5469351 69 ALL - REAR
- 4.910 SEAL, POWER BRAKE VACUUM CYLINDER FRONT HOUSING**
- 1 5452549 67-71 ALL
- 4.913 FILTER, POWER BRAKE VACUUM CYLINDER AIR**
- 1 5467788 67-71 ALL
- 4.913 RING, POWER BRAKE VACUUM CYLINDER SILENCER**
- 1 5460612 67-71 ALL
- 4.913 SILENCER, POWER BRAKE VACUUM CYLINDER**
- 1 5466534 67-71 ALL /SUP 5464781/
- 4.918 BUMPER, POWER BRAKE VACUUM CYLINDER REACTION**
- 1 5464318 67-71 ALL
- 4.918 RETAINER, POWER BRAKE VACUUM CYLINDER AIR VALVE SPRING**
- 1 5464316 67-71 ALL
- 4.918 RING, POWER BRAKE AIR VALVE SPRING RETAINER**
- 1 5464317 67-71 ALL
- 4.918 SEAL, POWER BRAKE VACUUM CYLINDER AIR VALVE /O/ RING**
- 1 5464319 67-71 ALL
- 4.918 SPRING, POWER BRAKE VACUUM CYLINDER AIR VALVE**
- 1 5465074 67 ALL
- 1 5463659 68-69 ALL
- 1 5464853 70-71 ALL

- 4.918 VALVE AND PUSH ROD ASSEMBLY, POWER BRAKE VACUUM CYLINDER AIR**
- 1 5462684 67 ALL
- 1 5468957 68 ALL
- 1 N.L.A. 69 ALL /SUP 5469359/
- 4.922 DIAPHRAGM, POWER BRAKE VACUUM CYLINDER POWER PISTON**
- 1 5467856 67-71 ALL
- 4.922 PISTON, POWER BRAKE VACUUM CYLINDER**
- 1 5467849 67-76 ALL - MORAINE
- 4.922 SUPPORT, POWER BRAKE VACUUM CYLINDER POWER PISTON DIAPHRAGM**
- 1 5467857 67-71 ALL
- 4.924 BEARING, POWER BRAKE VACUUM CYLINDER POWER PISTON**
- 1 5465205 67-71 ALL
- 4.924 ROD, POWER BRAKE VACUUM CYLINDER POWER PISTON ADJUSTER**
- 1 5464521 67 ALL
- 1 5462683 68-76 ALL EXC TANDEM SYSTEM - MORAINE
- 4.924 SEAL, POWER BRAKE VACUUM CYLINDER PISTON ROD /O/ RING**
- AR 5464332 67-71 ALL
- 4.924 SPRING, POWER BRAKE VACUUM CYLINDER POWER PISTON**
- 1 5464312 67-71 ALL
- 4.930 BRACKET, POWER BRAKE VACUUM PIPE**
- 1 9789088 67-69 ALL 6 CYL - 4BC
- 1 9789088 67 ALL 8 CYL
- 1 487160 72-74 ALL 8 CYL
- 4.930 CLAMP, POWER BRAKE VACUUM HOSE AND PIPE TO BRACKET**
- 1 1470029 67-69 ALL - 11/16 BLACK /SUP 3829058/
- 4.930 FITTING, POWER BRAKE VACUUM PIPE TO CARBURETOR**
- 1 9789089 67-69 ALL 6 CYL - 4BC
- 1 535247 67 ALL ST 8 CYL - 3 WAY
- 1 9792071 68 ALL 8 CYL - 3 WAY - HOSE TO CARB
- 1 9798890 69 ALL - 2 WAY - HOSE CONN TO CARB
- 1 9794423 69 ALL - 3 WAY - HOSE CONN TO CARB - 2-11/16 IN LONG
- 1 478417 70 ALL WITH POWER OR DISC BRAKES - 3 WAY - 2-11/16 IN LONG
- 1 478416 70 ALL - 4 WAY
- 1 3977105 70-71 6 CYL - VACUUM PIPE TO MANIFOLD
- 1 9794423 70-74 8 CYL - 2 WAY, HOSE CONN TO CARB - 2-11/16 IN LONG
- 4.930 FITTING, TRANSMISSION TO CARBURETOR VACUUM PIPE**
- 1 9784714 67 ALL WITH 400 ENGINE - WITH PB - 1 WAY
- 4.930 NUT, POWER BRAKE VACUUM CYLINDER TO CARBURETOR**
- 1 114965 68-69 ALL 6 CYL - 4BC - D.L. 3.278

**4.930 PIPE ASSEMBLY, INTAKE MANIFOLD TO
VACUUM CYLINDER**

1 3977200 70-72 ALL ST 6 CYL WITH PB
1 326575 73 6 CYL ENG WITH PB

**4.931 HOSE, VACUUM POWER BRAKE FITTING
TO VACUUM CYLINDER**

1 609863 67-70 ALL - 3/8 ID X 32 LG /SUP
542691/

**4.934 LEVER, POWER BRAKE VACUUM
CYLINDER REACTION**

3 5464313 67 ALL WITH DB
68-71 ALL

**4.934 PLATE, POWER BRAKE VACUUM
CYLINDER REACTION**

1 5463451 67 ALL EXC DB /SUP 5464376/
1 5452963 67 ALL WITH DB
68 ALL EXC DB
1 5460750 68 ALL WITH DB
1 5462191 69 ALL EXC DB
1 N.L.A. 69 ALL WITH DB - EXC TRANS AM
/SUP 5460750/
1 N.L.A. 69 ALL WITH DB - WITH TRANS AS
/SUP 5463451/
1 5452963 70-71 ALL

**4.934 RETAINER, POWER BRAKE VACUUM
CYLINDER REACTION LEVER**

1 5464282 67-71 ALL

**4.934 SPRING, POWER BRAKE VACUUM
CYLINDER REACTION PLATE**

1 5467283 67 ALL EXC DB

**4.935 RETAINER, POWER BRAKE VACUUM
CYLINDER FLOATING CONTROL VALVE**

1 5464369 67-71 ALL

**4.935 RING, POWER BRAKE VACUUM
CYLINDER CHECK VALVE LOCK**

1 5464328 67-71 ALL

**4.935 VALVE KIT, POWER BRAKE VACUUM
CYLINDER FLOATING CONTROL**

1 5464967 67-69 ALL

**4.955 GROMMET, POWER BRAKE VACUUM
CHECK VALVE**

1 5461808 67-72 ALL - 1/2 DIA

4.955 VALVE, POWER BRAKE VACUUM CHECK

1 18000139 67-75 ALL

18000139