

---

# GROUP 8.000 SHEET METAL

## ILLUSTRATION INDEX


Description	Page
1967-76 Sheet Metal .....	2-9

# GROUP 8.500 — HEATER

Description	Page
Spare Wheel and Jack Stowage .....	1
Heater and Defroster .....	2-5

---

**GM** **FIREBIRD**  
PARTS CATALOGUE




1967-68 FIREBIRD FRONT END SHEET METAL

**1967-68 FRONT END SHEET METAL**

Key	Description	Part No.	Qty.	Group
1	Bracket, Front License Plate	9788865	1	7.800
2	Panel, Front Bumper Valance—1967	9789297	1	7.833
	—1968	9792108	1	7.833
3	Baffle, Valance Panel to Sheet Metal	See Data	1	7.833
4	Support, Hood Latch	9788879	1	8.080
5	Latch Assy., Hood—1967	9712100	1	8.083
	—1968	9715566	1	8.083
6	Plate, Hood Latch Mounting	9789033	1	8.080
7	Plate, Hood Lift Spring Retainer	548753	1	8.083
8	Spring, Hood Lift—1967	548752	1	8.083
	—1968	9790484	1	8.083
9	Support Assy., Radiator—1967	3891660	1	1.270
	—1968	3962940	1	1.270
10	Filler, Radiator Cross Brace (not on all jobs)—Right	9794808	1	1.274
11	Bumper, Radiator Cross Brace Filler (not on all jobs)	9789299	4	1.274
12	Tray Assy., Battery			
	—6 Cyl.—With Air Cond.	3893882	1	2.333
	—6 Cyl.—With Air Cond.	9789148	1	2.333
	—8 Cyl.	3893882	1	2.333
13	Gusset, Front Fender Radiator Support—Right	9789031	1	8.153
14	Bumper, Hood—Hood to Fender Side —Front	9781945	2	8.024
15	Fender, Front—Right	9793816	1	8.130
	—Left	9793817	1	8.130
16	Reinforcement, Front Fender Center to Fender Skirt	3795490	4	8.143
17	Bumper, Hood—Hood to Fender Side Rear—1967	9875926	2	8.024
	—1968	9793284	2	8.024
18	Panel Assy., Hood			
	—1967/With 230 Engine	9788846	1	8.000
	—1967/With 326 Engine	9788846	1	8.000
	—1967/With 400 Engine	9789418	1	8.000
	—1968/With 250-350 Engines	9793429	1	8.000
	—1968/With 400 Engine	9793430	1	8.000
19	Emblem, Hood Side	See Data	2	8.030
20	Ornament, Hood side — With 400 Engine Exc. Ram Air — Right	9777957	1	8.030
	— Left	9777958	1	8.030
	With Ram Air — Right	9794283	1	8.030
	— Left	9794284	1	8.030
21	Seal, Hood Cowl Ledge	546103	1	12.801
22	Grille, Shroud Top Vent	9788864	1	12.800
23	Emblem, Hood Side — 326 or 350	See Data	2	8.030
24	Emblem, Hood Side — 400	See Data	2	8.030
25	Seal, Cowl Top Vent Grille	3891661	2	12.800
26	Hinge Assy., Hood—Right	3910668	1	8.015
	—Left	3910667	1	8.015
27	Clip, Hood Emblem to Hood — 6 Cyl.	9777953	2	8.039
28	Seal, Clutch Pedal Push Rod Hole	3903466	1	0.829
29	Cover, Clutch Pedal Push Rod Hole	3886689	1	0.829
30	Spring, Hood Hinge	3848272	2	8.013
31	Shroud, Radiator Fan — 8 Cyl.	9788883	1	1.277
32	Pad, Hood Insulator	9788847	1	8.021
33	Clip, Hood Insulator Pad Retainer	3977775	8	8.021
34	Brace, Front Fender Skirt—1967—Right	3898192	1	8.155
	—1967—Left	3898191	1	8.155
	—1968—Right	3919136	1	8.155
	—1968—Left	3919135	1	8.155

Key	Description	Part No.	Qty.	Group
35	Seal, Front Fender Skirt to Frame—Lower—Right	3899873	1	8.154
	—Left	3909123	1	8.154
36	Cap, Radiator Filler	861050	1	1.203
37	Skirt, Front Fender—1967—Right	9777835	1	8.153
	—1967—Left	9792121	1	8.153
	—1968—Right	9792120	1	8.153
	—1968—Left	9792121	1	8.153
38	Seal, Front Fender Skirt to Frame—Upper	3909121	2	8.154
39	Tube, Radiator Overflow	9776395	1	1.240
40	Brace, Front Fender to Radiator Support—Right	3903480	1	8.155
41	Bumper, Radiator Fan Guard — 6 Cyl.	3745361	2	1.277
42	Clip, Radiator Fan Shroud — 8 Cyl. —Right	3899881	1	1.277
43	Radiator Assembly	See Data	1	1.219
44	Clip, Radiator Fan Shroud — 8 Cyl. —Left	3899880	1	1.277
45	Bracket Assy., Radiator Fan Shroud —8 Cyl.	3938612	1	1.277
46	Guard, Radiator Fan — 6 Cyl.	3893892	1	1.277
47	Bumper, Hood—Hood Front	3792828	2	8.024
48	Screw, Hood Adjuster Front Bumper	3839682	2	8.024
49	Nut	274218	AR	8.917
50	Gusset, Front Fender Radiator Support —Left	9789032	1	8.153
51	Brace, Front fender to Radiator Support —Left	3903479	1	8.155
52	Shim, Front Fender Alignment	3711834	30	8.143
53	Fender, Front—Left	9793817	1	8.130
54	Moulding Package, Front Fender Wheel Opening—Right	9785880	1	8.147
	—Left	9785881	1	8.147
55	Plate, Front Fender Name	9789532	2	8.147
56	Emblem, Front Fender	9789589	2	8.147
57	Extension, Front Fender—1967—Right	3891628	1	8.131
	—1967—Left	3891627	1	8.131
	—1968—Right	9792103	1	8.131
	—1968—Left	9792104	1	8.131
58	Brace, Hood Latch	9794962	1	8.080
59	Clip, Front Frame Bar Seal (Not on all jobs)	9770153	6	7.865
60	Reinforcement, Front Fender Center to Fender Skirt	3795490	4	8.143
61	Dampner, Body Front (-67 Models)	See Data	AR	9.007
62	Seal, Front Bumper Frame Bar to Sheet Metal	See Data	AR	7.865
63	Filler, Radiator Cross Brace (not on all jobs)—Left	9794809	1	1.274
64	Shield and Bracket Assy., Body to Frame Splash—Right	9792558	1	8.153
	—Left	9792559	1	8.153




**1969 FIREBIRD FRONT END SHEET METAL**



**1969 FIREBIRD FRONT END SHEET METAL**

Key	Description	Part No.	Qty.	Group
1	Bracket, Front License Plate—Mounting	9795476	1	7.800
2	Panel, Front Bumper Valance	9796087	1	7.833
3	Baffle, Valance Panel to Sheet Metal	See Data	1	7.833
4	Support, Hood Latch	9794823	1	8.080
5	Latch Assy., Hood	9718500	1	8.083
6	Plate, Hood Latch Mounting	9789033	1	8.080
7	Plate, Hood Lift Spring Retainer	548753	1	8.083
8	Spring, Hood Lift	9790484	1	8.083
9	Support Assy., Radiator	3962940	1	1.270
10	Filler, Radiator Cross Brace—With 250-350 Eng.—With Air Cond.—Right	9794808	1	1.274
	With 250-350 Eng.—With Air Cond.—Left	9794809	1	1.274
	With 400 Engine—Right	9794808	1	1.274
	With 400 Engine—Left	9794809	1	1.274
11	Bumper, Radiator Cross Brace Filler —With 250-350 Engines—With With Air Cond.	9789299	4	1.274
	With 400 Engine	9789299	4	1.274
12	Tray Assy., Battery —6 Cyl.—Exc. Air Cond.	3893882	1	2.333
	—6 Cyl.—With Air Cond.	9789148	1	2.333
	—8 Cyl.	3893882	1	2.333
13	Gussett, Front Fender Radiator Support —Right	9789031	1	8.153
	—Left	9789032	1	8.153
14	Bumper, Hood—Hood to Fender Side—Front	9781945	2	8.024
15	Fender, Front—Right—Exc. Trans. AM	9798212	1	8.130
	—Left—Exc. Trans. AM	9798213	1	8.130
16	Reinforcement, Front Fender Center to Fender Skirt	3795490	4	8.143
17	Bumper, Hood to Fender Side—Rear	9797731	2	8.024
18	Panel Assy., Hood—With 250-350 Engines —With 400 Engine—Exc. Cable Control Hood Air Inlet	9793429	1	8.000
	—With 400 Engine—With Cable Control Hood Air Inlet—Exc. Trans. AM	9797763	1	8.000
	—With Trans. AM	546014	1	8.000
19	Seal, Hood Cowl Ledge	546103	1	12.801
20	Grille, Shroud Top Vent	9788864	1	12.800
21	Seal, Cowl Top Vent—Grille	3891661	2	12.800
22	Hinge Assy., Hood—Right	3910668	1	8.015
	—Left	3910667	1	8.015
23	Seal, Clutch Pedal Push Rod Hole	3903466	1	0.829
24	Cover, Clutch Pedal Push Rod Hole	3886689	1	0.829
25	Spring, Hood Hinge —With 250-350 Engines	3848272	2	8.013
	—With 303-400 Engines	546325	2	8.013
26	Shroud, Radiator Fan—8 Cyl.	9788883	1	1.277
27	Pad, Hood Insulator	9788847	1	8.021
28	Clip, Hood Insulator Pad Retainer	3977775	8	8.021
29	Brace, Front Fender Skirt—Right	3919136	1	8.155
	—Left	3919135	1	8.155
30	Seal, Front Fender Skirt to Frame—Lower	3909123	2	8.154
31	Cap Assy., Radiator Filler	3886273	1	1.203


Key	Description	Part No.	Qty.	Group
32	Skirt, Front Fender—Right	9796531	1	8.153
	—Left	9796532	1	8.153
33	Seal, Front Fender Skirt to Frame—Upper	9798977	2	8.154
34	Tube, Radiator Overflow	9776395	1	1.240
35	Brace, Front Fender to Radiator Support —Right	3903480	1	8.155
	—Left	3903479	1	8.155
36	Nut, Radiator to Radiator Support	3903539	1	1.270
37	Clip, Radiator Fan Shroud—Right	3899881	1	1.277
	—Left	3899880	1	1.277
38	Radiator Assy. *See Chart in Group 1.000 Illustrations	*	1	1.219
39	Bracket, Radiator Fan Shroud—8 Cyl.	3938612	1	1.277
40	Guard, Radiator Fan —6 Cyl.—Exc. Air Cond.	3893892	1	1.277
	—6 Cyl.—With Air Cond.	9798137	1	1.277
41	Bumper, Hood—Hood Front	3792828	2	8.024
42	Screw, Hood Adjuster Front Bumper	3839682	2	8.024
43	Nut	274218	2	S.S.
44	Shim, Front Fender Alignment	3711834	AR	8.143
45	Brace, Hood Latch	9794962	1	8.080
46	Clip, Front Frame Bar Seal —6 Cyl. with Air Cond.	9770153	6	7.865
	—8 Cyl.	9770153	6	7.865
47	Dampener, Bracket and Spacer, Body Front (-67) Models—Right	9797614	1	9.007
	—Left	9797615	1	9.007
48	Seal, Front Bumper Frame Bar to Sheet Metal	See Data	2	7.865
49	Bolt, Body Hold Down—No. 1	3914816	2	9.008
50	Washer, Body Bolt—No. 1	3901365	2	9.011
51	Cushion, Body to Frame—No. 1—Upper	3893159	2	9.023
52	Cushion, Body to Frame—No. 1—Lower	3893156	2	9.023
53	Washer, Body Bolt—No. 1	1305797	2	9.023
54	Washer	103329	2	Cat.907A
55	Nut	9414511	2	Cat.907A
56	Shield and Bracket Assy., Body to Frame Splash—Right	9792558	1	8.153
	—Left	9792559	1	8.153
57	Bumper, Front Fender Support	9797328	2	8.153
58	Bracket, Front Fender Skirt to Dampener—Right	9796078	1	8.153
	—Left	9796079	1	8.153
59	Bumper, Front Fender Support	9797328	2	8.155
60	Support, Front Fender—Right (-37) Only	9797452	1	8.155
	—Left (-37) Only	9797453	1	8.155
61	Bracket, Front Bumper Valance Panel Mounting	9796233	1	7.833
62	Lever, Hood Latch Release	9796288	1	8.083
63	Grommet, Hood Latch Release Lever	9787186	1	8.083
64	Support, Front Bumper Valance Panel to Lower Reinforcement—Right	9796897	1	7.833
	—Left	9796898	1	7.833



**1970-75 FRONT END SHEET METAL**

## 1970-75 FRONT END SHEET METAL (TYPICAL)


Key	Part Name	Group No.	Key	Part Name	Group No.
1	FENDER, Front - R.H.	8,130	46	RETAINER, Rad. Support Insul. Nut	1,270
2	BUMPER, Hood to Fender - Side	8,024	47	NUT, Rad. Support to Frame Insul. (7/16"-14 U Shape)	1,270
3	SKIRT, Front Fender	8,153	48	PANEL, Fender Skirt to Rad. Support Closeout	8,153
4	BRACKET, Front Fender Skirt to Body	8,153	49	SUPPORT & BAFFLE, Radiator	1,270
5	PANEL, Hood	8,000	50	RETAINER, Radiator Insulator Mtg.	1,270
6	MOLDING, Hood Rear	8,054	51	LATCH, Hood	8,083
7	PAD, Hood Insulator	8,021	52	SUPPORT, Frt. End Sheet Metal - Vertical	8,155
8	SCREEN, Shroud Top Vent	12,800	53	GROMMET, Hood Lock Release	8,083
9	CLIP, Hood Pad Insul. Retainer	8,021	54	SPOILER, Frt. at Valance	7,833
10	SHROUD, Radiator Fan	1,277	55	PANEL, Frt. Bumper Valance (Steel)	7,833
11	CLIP, Ground Hood	9,647	56	BRACKET, Frt. Valance Panel Center Mtg.	7,833
12	CLIP, Impact Bar to Body Snubber	7,829	57	LEVER, Hood Latch Release	8,083
13	BUMPER, Hood Rear	8,024	58	BRACKET, Hood Latch Release Lever	8,083
14	PLUG, Shroud Gauge Hole	8,153	59	SPRING, Hood Pop Up	8,083
15	SEAL, Body to Hood	12,801	60	FILLER, Frt. End Sheet Metal Brace to Bumper	8,155
16	HINGE, Hood	8,015	61	PANEL, Upper Mtg. and Frame - Guard	1,277
17	MOLDING, Frt. Fender Upper Rear	8,147	62	NUT, Hood Adjustable Bolt Lock (5/16"-18)	8,900
18	SHIM, Front Fender to Shroud	8,143	63	BUMPER & BOLT, Hood Adjustable	8,024
19	SPRING, Hood Hinge	8,013	64	INSULATOR, Upper Mtg. & Fan Guard	1,270
20	SEAL, Clutch Pedal Push Rod Hole	0,829	65	CAP, Radiator Filler	1,203
21	COVER, Clutch Pedal Push Rod Hole	0,829	66	TUBE, Radiator Overflow	1,240
22	DRAIN COCK, Radiator	8,951	67	RADIATOR (See Chart for Usage)	1,219
23	INSULATOR, Radiator Bracket - Lower	1,270	68	INSULATOR, Radiator - Upper	1,270
24	FENDER, Front - L.H.	8,130	69	NAME PLATE PKG., Front Fender "Formula - 350"	8,147
25	MOLDING PKG., Front Fender Wheel Opening	8,147	70	NAME PLATE PKG., Front Fender "Formula - 455"	8,147
26	NAMEPLATE PKG., Front Fender "Formula 400"	8,147	71	LOUVER PKG., Front Fender (1971)	8,147
27	EMBLEM PKG., Front Fender "350"	8,147	72	DECAL, Hood Name "Ram Air"	8,055
28	NAMEPLATE PKG., Front Fender "Firebird"	8,147	73	MOLDING PKG., Fender - Side (1971-74)	8,147
29	EXTRACTOR, Front Fender Air	8,147	74	BRACKET, Panel to Radiator Support (1971-74)	7,833
30	DECAL, Front Fender "Trans. Am"	8,147	75	EMBLEM PKG., Front Fender (1972-73)	8,147
31	SPOILER, Front Fender Wheel Opening	8,147	76	BRACE, Bumper to Hood Opening Reinforcement	7,833
32	BEZEL, Frt. Side Marker Lamp	2,575	77	PIN, Hood Latch Release Cable Clevis	8,075
33	LAMP ASM., Side Marker - Frt.	2,575	78	CLIP, Hood Release Cable	2,343
34	SHIM, Radiator Support Insulator (.120 thick)	1,270	79	SPRING, Hood Pop-up	8,083
35	INSULATOR, Radiator Support to Frame - Lower	1,270	80	CABLE ASM., Hood Latch Release	8,075
36	INSULATOR, Radiator Support to Frame - Upper	1,270	81	BRACKET, Hood Latch Release Cable	8,083
37	SHIM, Radiator Support to Frame (.060 thick)	1,270	82	GROMMET, Hood Latch Release Cable	9,775
38	PLATE, Radiator Support Insulator	1,270	83	BRACKET, Hood Latch Release Rod Guide (1974)	8,083
39	TRAY, Battery	2,333	84	SUPPORT, Frt. End Panel - Center (1974)	1,266
40	BRACKET, Radiator Mounting Lower	1,274	85	SUPPORT, Frt. End Panel to Baffle (1974)	1,266
41	LAMP ASM., Parking	2,585	86	SUPPORT, Frt. End Panel - Outer (1974)	1,266
42	FILLER, Parking Lamp	2,587			
43	BOLT, Rad. Insul. to Frame (7/16"-14 x 2 7/8")	1,270			
44	SLEEVE, Radiator Support Insulator	1,270			
45	NUT, Support to Frame Insul. (7/16"-14)	1,270			



1976 "F" FRONT END SHEET METAL


**1976 "F" FRONT END SHEET METAL**

1. FENDER, Front - RH	8.130	42. TRAY, Battery	2.333
2. BUMPER, Hood to Fender-Side	8.024	43. PLUG (3/4")	N.S.
3. HINGE, Hood	8.015	44. BRACKET, Hood Latch Release Guide	8.083
4. SPRING, Hood Hinge	8.013	45. SUPPORT, Frt. End Panel-Center	1.266
5. DECAL, Hood Scoop	8.055	46. PANEL, Frt. End & Headlamp Mounting	1.263
6. DECAL, Hood-Firebird	8.055	47. DECAL, Frt. End Panel "Formula"	1.303
7. SEAL, Body to Hood	12.801	48. DECAL, Frt. End Panel "Trans Am"	1.303
8. SCREEN, Shroud Top Vent	12.800	49. EMBLEM PKG., Crest	1.303
9. BUMPER, Hood Rear	8.024	50. SUPPORT, Frt. End Panel-Outer	1.266
10. MOLDING, Hood Rear	8.055	51. BOLT, Rad. Insul. to Frame (7/16"—14 x 27/8")	1.270
11. DECAL, "455 HO"	8.055	52. SHIM, Rad. Support Insulator (.120 thick)	1.270
12. DECAL, "400"	8.055	53. INSULATOR, Rad. Support to Frame-Lower	1.270
13. PANEL ASM., Hood	8.000	54. SLEEVE, Rad. Support Insulator	1.270
14. PAD, Hood Insulator	8.021	55. INSULATOR, Rad. Support to Frame-Upper	1.270
15. SHROUD, Radiator Fan	1.277	56. NUT, Support to Frame Insul. (7/16"—14)	1.270
16. INSULATOR, Radiator-Upper	1.270	57. SHIM, Rad. Support Adjusting	1.270
17. CAP, Radiator Filler	1.203	58. PLATE, Rad. Support Insulator	1.270
18. RADIATOR ASM.	1.219	59. HORN ASM.	2.810
19. DRAIN COCK, Radiator	8.951	60. RETAINER, Rad. Insulator Mtg.	1.270
20. INSULATOR, Radiator Bracket-Lower	1.270	61. LATCH, Hood	8.083
21. BRACKET, Radiator Mounting-Lower	1.274	62. SUPPORT, Frt. End Panel Vertical	1.266
22. MOLDING, Frt. Fender Upper Rear	8.132	63. LEVER, Hood Latch Release	8.083
23. FENDER, Front - LH	8.130	64. BRACKET, Hood Latch Release Lever	8.083
24. MOLDING PKG., Fender-Side	8.132	65. SUPPORT & BAFFLE ASM., Radiator	1.270
25. STRIPE, Frt. Fender-Lwr. Rear	8.132	66. SPRING, Hood Pop Up	8.083
26. DECAL, Front Fender-"Trans Am"	8.147	67. BAFFLE, Radiator Support Air	1.272
27. DECAL, Front Fender-"Formula"	8.147	68. STRAP, Emission Control Canister Mtg.	3.130
28. PLATE PKG., Front Fender Name "Firebird"	8.147	69. INSULATOR, Upper Mtg. & Fan Guard	1.270
29. STRIPE, Front Fender	8.132	70. PANEL, Rad. Upper Mtg. & Fan Guard	1.277
30. EXTRACTOR, Front Fender Air	8.131	71. RESERVOIR, Coolant Overflow	1.240
31. MOLDING PKG., Front Fender Wheel Opening	8.132	72. BRACKET, Reservoir Mounting	1.240
32. STRIPE, Frt. Fender-Lwr. Frt.	8.132	73. CAP, Coolant Reservoir	1.240
33. SPOILER, Frt. Fender Wheel Opening	8.131	74. SEAL, Skirt to Frame	8.154
34. BEZEL, Frt. Side Marker Lamp	2.575	75. BRACKET, Frt. Fender Skirt to Body	8.153
35. PANEL, Fender Skirt to Rad. Support Closeout	8.153	76. SKIRT, Front Fender	8.153
36. LAMP ASM., Side Marker-Frt.	2.575	77. BUMPER, Hood Adjustable	8.024
37. SKIRT, Front Fender	8.153	78. PLATE PKG., Frt. Fender Name "Esprit"	8.147
38. BRACKET, W/S Washer Jar Mounting	10.154	79. ORNAMENT, Hood Top Vent	8.055
39. JAR, Windshield Washer	10.154	80. CLIP, W/S Antenna Ground Hood	9.647
40. RETAINER, Battery Hold Down	2.335	81. NOZZLE, W/S Washer	10.156
41. BOLT, Battery Hold Down	2.334		



**SPACE SAVER TIRE (COUPE)**


Key	Part Name	Group No.
1	SLEEVE, Jack Post & Handle . . . . .	8.821
2	BOLT, Spare Wheel Clamp . . . . .	7.632
3	HANDLE, Jack. . . . .	8.820
4	JACK ASM., Bumper . . . . .	8.820
5	BASE ASM., Bumper Jack . . . . .	8.820
6	INFLATOR, Tire . . . . .	5.880
7	RETAINER, Tire Inflator . . . . .	5.880
8	NUT, Spare Wheel Clamp Bolt . . . . .	7.633



**CONVENTIONAL TIRE (CONVERTIBLE)**

Key	Part Name	Group No.
1	NUT, Spare Wheel Clamp Bolt . . . . .	7.633
2	BASE ASM., Bumper Jack . . . . .	8.820
3	BOLT, Spare Wheel Clamp . . . . .	7.632
4	SLEEVE, Jack Post & Handle . . . . .	8.821
5	HANDLE, Jack . . . . .	8.820
6	JACK ASM., Bumper . . . . .	8.820

**FIREBIRD SPARE WHEEL AND TOOL RETAINER**



**1967-68 FIREBIRD HEATER**  
GROUP 8.500 ILLUSTRATION 2



**1967-68 FIREBIRD HEATER**

Key	Part Name	Group No.
1	NOZZLE, Defroster Air . . . . .	9.779
2	BULB, Heater Control Lamp (#1895) . . . . .	8.991
3	SCREW, Heater Blower Switch (#10-24 x 3/8") . . . . .	8.977
4	SWITCH ASM., Heater Blower . . . . .	8.852
5	NUT, Heater Blower Switch . . . . .	8.852
6	BUSHING, Heater Control Switch Lever . . . . .	8.866
7	CONTROL ASM., Heater . . . . .	8.849
8	SCREW, Air Control Cable to Heater Control (#10-16 x 5/8") . . . . .	8.977
9	SCREW, Control Asm. to Inst. Panel (#10 x 16 x 3/4") . . . . .	8.977
10	CABLE ASM., Heater Air Control . . . . .	8.849
11	CABLE ASM., Heater Temperature Control . . . . .	8.849
12	CABLE ASM., Defroster Control . . . . .	9.779
13	NUT, Control Cable to Heater Control . . . . .	8.866
14	SCREW, Air Distributor Outlet to Dash . . . . .	8.846
15	SHAFT & LEVER ASM., Heater Temperature . . . . .	9.786
16	SEAL, Heater Core Tube . . . . .	8.846
17	CORE ASM., Heater . . . . .	8.854
18	VALVE, Temperature Control . . . . .	8.866
19	CASE ASM., Heater . . . . .	8.854
20	BEARING, Temperature Valve Pin . . . . .	8.866
21	CLAMP, Outlet Hose to Heater Case (7/8" to 1-1/4" I.D.) . . . . .	8.846
22	HOSE, Heater Inlet Water (5/8" I.D. x 20") . . . . .	8.846
23	CLAMP, Inlet Hose (7/8" to 1-1/4" I.D.) . . . . .	8.846
24	NIPPLE, Inlet Hose to Engine . . . . .	8.866
25	HOSE, Heater Outlet Water (3/4" I.D. x 45") . . . . .	8.846
26	CLIP, Heater Outlet Hose . . . . .	N.S.
27	HOSE, Heater Inlet Water (5/8" I.D. x 20") . . . . .	8.846
28	INSULATOR, Heater Outlet Water Hose . . . . .	3.162
29	HOSE, Heater Water Outlet (Exc. A.I.R.) (3/4" I.D. x 35-1/2") . . . . .	8.846
30	HOSE, Heater Water Outlet (With A.I.R.) (3/4" I.D. x 48-1/2") . . . . .	8.846
31	BRACKET, Heater Water Hose . . . . .	8.846
32	SCREW, Blower Motor to Case (#8-18 x 3/8") . . . . .	8.977
33	LOCKWASHER, Motor to Case (#8-Ext.) . . . . .	8.932
34	MOTOR ASM., Heater Blower . . . . .	8.855
35	IMPELLER, Heater Blower . . . . .	8.857
36	LOCKWASHER, Impeller to Motor (#10) . . . . .	8.932
37	NUT, Impeller to Motor (#10-32) . . . . .	8.915
38	SCREW, Duct to Shroud . . . . .	N.S.
39	CABLE ASM., Blower Air Inlet . . . . .	8.857
40	NUT, Inlet Duct to Dash (1/4"-20) . . . . .	8.921
41	WASHER, Inlet Duct to Dash . . . . .	N.S.
42	DUCT, Heater Air Distribution - Front . . . . .	9.786
43	SCREW, Distribution Duct to Heater (#10-16 x 5/8") . . . . .	8.977
44	OUTLET, Heater Air Distribution - Left End . . . . .	9.786
45	NUT, Defroster Shaft to Case . . . . .	N.S.
46	CLIP, Heater Air Control Cable . . . . .	N.S.
47	SHAFT & LEVER ASM., Defroster . . . . .	9.779
48	SCREW, Resistor to Case (#10-16 x 1/2") . . . . .	8.977
49	RESISTOR ASM., Heater Blower Motor . . . . .	8.852
50	WIRE HARNESS, Instrument Panel . . . . .	2.480






**1969-75 FIREBIRD HEATER**

Key	Description	Part No.	Qty.	Group
1	Seal, Defroster Nozzle to Instrument Panel (6 Cyl.)			9.779
2	Nozzle Assy., Defroster Air			9.779
3	Grommet, Accessory Wire Thru Dash			9.775
4	Seal, Heater Core Tubes to Dash			8.846
5	Core, Heater			8.854
6	Wire, Heater Control			8.866
7	Screw — #10 - 16 x ½			Std. Stk.
8	Resistor Assy., Heater Blower Motor			8.852
9	Cable Assy., Heater Temperature Control			8.849
10	Case Assy., Heater			8.854
11	Bracket, Heater Temp. Control Cable Mounting			8.866
12	Screw — #10 - 16 x ½			Std. Stk.
13	Switch, Heater Blower and Air Cond. Motor			8.852
14	Control Assy., Heater and Air Cond.			8.849
15	Support, Heater and Air Cond. Controls			8.852
16	Nut			N.L.
17	Washer			Std. Stk.
18	Screw			N.S.
19	Screw — #10 - 16 x ¾			Std. Stk.
20	Duct, Heater Air Distributor			9.786
21	Screw — #10 - 16 x ¾			Std. Stk.
22	Cable, Heater Air Control			8.849
23	Cable Assy., Heater Defroster Control			9.779
24	Screw — #10 - 16 x ¾			Std. Stk.
25	Washer — ½ ID x ¾ OD			Std. Stk.
26	Washer			N.S.
27	Case Assy., Blower Air Inlet			8.857
28	Nut — ¼ - 20			
29	Clip			Std. Stk.
30	Motor, Heater Blower			8.855
31	Impeller, Heater Blower			8.857
32	Screw — ¼ - 14 x 1			Std. Stk.
33	Clamp, Heater Hose			Std. Stk.
34	Hose, Heater Inlet — ¾ ID			Std. Stk.
35	Hose, Heater Outlet — ¾ ID			Std. Stk.
36	Spacer, Heater Outlet Hose			8.846
37	Nipple, Heater Hose to Cylinder Head			8.866
38	Bracket, Heater Water Hose			8.846
39	Bracket, Heater Water Hose			8.846
40	Nut — #10 - 16 - U -			Std. Stk.
41	See Key #15			

N.S. — NOT SERVICED.

NOTE: FOR STANDARD STOCK ITEMS, REFER TO CATALOGUE P AND A 907



P8-13

**1976 "F" HEATER**

1. OUTLET ASM., Defroster .....	9.779	13. SCREW (#10-16 x 3/4" AB) .....	8.977
2. SCREW (#10-16 x 3/4") .....	8.977	14. NUT (10-16 "U") .....	2.587
3. GASKET, Htr. & Defr. ....	8.854	15. SCREW (#10-16 x 3/4") .....	8.977
4. CORE, Heater .....	8.854	16. SUPPORT, Htr. Control .....	8.852
5. SCREW (#10-16 x 1/2") .....	N.S.	17. CLAMP, Hose .....	1.188
6. NUT, Push-On (9/32") .....	9.779	18. HOSE, Heater Outlet .....	8.846
7. RESISTOR, Blower Motor .....	8.852	19. HOSE, Heater Inlet .....	8.846
8. CASE, Heater .....	8.854	20. SCREW (1/4"-14 x 1") .....	8.977
9. CABLE, Temp. Control .....	9.787	21. FAN, Htr. Motor .....	8.857
10. CABLE, Air Inlet & Defr. ....	9.787	22. SCREW (1/4"-14 x 1") .....	8.977
11. DUCT, Htr. Air Outlet .....	9.786	23. CASE, Blower & Inlet .....	8.857
12. CONTROL ASM., Heater .....	8.849	24. NUT (1/2"-20) .....	8.921